

INSTRUCTION MANUAL AND PARTS CATALOGUE FOR

THE ALBUTT RANGE OF YARDSCRAPERS

THIS MUST BE USED IN CONJUNCTION WITH ALBUTT'S GENERAL OPERATOR'S MANUAL

www.albutt.com | 01242 620 252 | keith@albutt.co.uk



OPERATING INSTRUCTIONS TELESCRAPE YARDSCRAPERS

Model	Width	Blade Height	Depth	Weight
YS50GV	2.2m to 3.1m	530 mm	1130 mm	490 kgs
YS30GV	1.8m to 2.7m	530 mm	1130 mm	470 kgs

SCRAPE POSITION

With the blade on floor, the pivot pin should be positioned in the centre of the slot. The pivot pin will float up and down inside the slot to accommodate gradients and uneven surfaces. Excessive down pressure on the pivot pin should be avoided. The weight of the blade provides sufficient ground pressure.



LIFT POSITION

The blade can be lifted and kept in the horizontal plane. The hook at the base of the pivot arm should be hooked under the plate adjacent to the main pivot pin. This can be achieved by lowering the telehandler boom and crowding the top of the carriage back towards or away from the handler, depending on position of the scraper blade.



TO REVERSE BLADE

Lift the boom of the telehandler allowing the pivot pin to rest in the bottom of the floating slot. Lift the scraper blade clear of ground allowing it to swing. Lower the boom allowing the blade to rest on the floor on rocker plates. Carefully drive the machine forwards or backwards allowing the scraper blade to roll over. Position the main pivot pin in the middle of the float slot and continue to scrape.



www.albutt.com | 01242 620 252 | keith@albutt.co.uk

	D.M.G		DATE	6-3-18				2						ŋ		4 V) A V 00	
H	Ċ	Albutt	NO														т
	Ъ		CAT	NEW DRAWING										<u>م</u>			
	SHEEI	MUST NOT MUST NOT RECONSENT.		D MEN										<u></u>	-		
U		OF ALBUIT LTD, AND / DF ALBUIT LTD, AND / BE USED WITHOUT THE										2				z)	U
100	-		TOLERANCE ISS		±0.5* ±0.2	u.						کھ (₹ €		Æ		_
		MBOLS IO BE FRE 35 TO BE FRE FECTS.	NCED DIM	2001 UP TO 2000 - 2001 AND ABOVE	ANGLES DRILED HOLES	ALL DIMENSIONS IN						1			2		
L.		R S	5 (888	-									$\left(\right)$			u.
(manual)		CTION									ď)-					-
ш		THIRD ANGLE PROJECTION												Ŵ			ш
															Ē		
		0															
	2	JBT ASK.															
U	- SPAKI	DO NOT SCALE - IF IN DOUBT ASK	1	2	64 6	- 1	2	4 .	4 c	101	4 c	40	4	4 4	5		U
	APEK -	DO NOT SC/					BER		AL	CLAMP PI	CLAMP PI		ŧ		. 0		
	D SCK		DESCRIPTION CENTER BLADE	MING		AIN FRAME	MAIN FRAME RUBBER	WING RUBBER	SECTION CA	TRE RUBBER O	YS30 / YS50 SIDE RUBBER CLAMP PI		M10 Nylock Nut	2 NMOCK NL	M10 Bolt x 70 Lg		
8	n YAK					×	MAIN	M	Š,	YS50 CENT	S30 / YS50 S		W	W	WI		æ
A B C	0 3.11		1	2			2	5	• -		2						
	1 WZ.7		PART NUMBER 28GV (Center) (4)	28GV-W	0-216P	01-0628GV-BF	01-0628-28	01-0628-29	20806	8-03L (2)	01-0628-04L (2)	1060BI	FSM10LN	FSM1280BL FSM12LN	FSM1070BL		
۷	2000		PART I 01-0628GV	01-0628GV-W	01-30-2	01-062	01-0	010	215	01-0628-0	01-062	ESMI	FSN	FSM	FSMI		A
	ŝ		CN PEL	2	m •	t 40	9	2 2	0 0	0	<u>۲</u>	1 2		2 Y	21	4 v v v v v	

	SHEET OF D.M.G		IS MODIFICATION DATE	1 NEW DRAWING 6-3-18				2			_		0	:		2		4
		A2 MELLI STIMBOLS TO BE FREE AULWEIDS TO BE FREE FROM DEFECTS.	RANCED DMENSIONS SIE TOLERANCE TO 500 ±1 IO 1000 ±1.5	1001 UP 10 2000 ±2 2001 AND ABOVE ±3	DRILED HOLES ±0.2 ALL DIMENSIONS IN mm		2			L. L.					-	0.		THA
ш								(n)-								4	e la
C	SPARES	DO NOT SCALE - IF IN DOUBT ASK.	017	2	2	2	-	2	4	4	2	2	4	61 6	1 4	Æ	¢	2
8	YS30GV 1.8m to 2./m YARD SCRAPER - SPARES	DO NOT SCA	DESCRIPTION	MING	PIVOT PIN	PIN	MAIN FRAME	MAIN FRAME RUBBER	WING RUBBER	BOX SECTION CAP	LOCKING PIN	YS30 CENTRE RUBBER CLAMP PI	YS30 / YS50 SIDE RUBBER CLAMP PI	LYNCH PIN	M10 Nylock Nut		M12 Nylock Nut	M10 Bolt x 70 Lg
	to 2./	-	4 ISS	2	-	-	-	2	2	÷	1	2	2	•				
A	30GV 1.8m 1		01-0630GV (Center) (4)	01-0628GV-W	01-30-216P	01-40-140P	01-0628GV-BF	01-0630-28	01-0628-29	PC80806	01-0901-K	01-0630-03L (2)	01-0628-04L (2)	FSTTMMLP	FSMTOLN	FSM1280BL	FSM12LN	FSM10708L
2	S.		CINE	5	e	4	5	2 6	7	œ	6	0	=	2 2	2 7	15	16	17